



5X-809 SUPER POWER BASS

Owner's Guide



CONTENTS

Contents	2
Important Safety Instructions	
Technical Specifications	
Preservation	
Cleaning	
Warranty	
Components	
Powering On/Off	
Channel Selection	
Battery & Charging	6
Volume Adjustment	
FAQ - Frequently Asked Questions	
Trademarks & Patents	

28-808

Important Safety Instructions

Proper Use

These headphones have been designed to be used only with Silentsystem® branded devices. LEM International s.r.l. reserves the right not to provide support if malfunctions arise due to improper use.

Before using the headphones, it is advisable to carefully read the instructions. We strongly recommend to retain this manual.

For Your Safety

Please read carefully and observe important safety information listed below.

- DO NOT use the headphones at high volumes for extended periods of time;
- To avoid hearing damage, use the headphones at a moderate and comfortable volume level;
- 2. Turn up the volume gradually until you reach an adequate listening level.
- DO NOT use headphones if they emit loud and unusual noises. In this case, turn off the headphones and contact LEM International s.r.l.;
- DO NOT immerse or expose the headphones to water for prolonged periods or wear them while practicing water sports, eg. swimming, water skiing, surfing, etc.;
- DO NOT expose to heat sources;
- DO NOT place heavy objects on the device;

- Remove the headphones immediately if you feel a sensation of heat or perceive a drop in audio performance;
- If skin irritation occurs, stop using the headphones;
- DO NOT throw, drop or let the headphones undergoing a heavy impact;
- DO NOT make unauthorized modifications to this product.



The lithium-ion battery built into this model cannot be removed. In case of any malfunctions, please contact LEM International s.r.l. immediately.





Technical Specifications

Power Supply: DC 3.7 V, built-in rechargeable

lithium-ion polymer battery **Battery Capacity**: 500 mAh **Speakers Driver**: Mylar 40mm

Use and Storage Temperature: $5 \, ^{\circ}\text{C} - 35 \, ^{\circ}\text{C}$

Working Dimensions:

Worn: 180x140x80mm Not Worn: 150x110x80mm

Weight: 225 grams

Frequency Response: 30-20.000 Hz

Preservation

- · When not in use, turn off the headphones;
- If you plan to not using the headphones for some time, please fully charge the battery.

Cleaning

These headphones require periodic cleaning.

LEM International s.r.l. recommends **Norica Plus** ® product, which can be freely purchased in pharmacies and parapharmacies (in Italy). Alternatively, you can clean the headphones with a cotton swab previously dipped in alcohol.

Warranty

This System (in all its components) is covered by a warranty for a period of 12 months starting from the date of purchase.

ΕN

Components



Pic. 1 - SX 809 Headphones

The Channel Selector, the On/Off Switch and the Charging Connector are located on the left earcup, identified by the letter L, clearly visible at the joint between the earcup and the upper arch, on the outside of the headset. Consequently, the volume control wheel is located on the right earcup, identified by the letter R.

Powering On/Off

To turn on the headphones, simply move the **On/Off Switch in the direction of the Channel Selector**; by doing so the earcups will light up with a color between Blue, Green or Red, according to the position of the Channel Selector.

It is important to clarify that, in case of the WL model (without LED), the headphones will not light up once switched on.

Consequently, to proceed with the shutdown, move the **On/Off Switch in the direction of the Charging Connector**.

Channel Selection

In order to listen what is being broadcasted by the Silentsystem ® trasnmitter, it is necessary to select the same channel on the headphones, using the **Channel Selector** switch (Pic. 1).

CHANNEL	RGB COLOR
1	BLUE
2	RED
3	GREEN

The heaphones are also available in a 10 Channels Version

Battery & Charging

When the built-in battery of the headset is low (10% of the remaining charge) the earcups will start flashing; it is therefore recommended to proceed with recharging of the device.

Proceed by placing the On/Off Switch in the direction of the Charging Connector

(Headphones Off).

The headset is recharged using the cable with proprietary connector (Pic. 2), and a full charge requires about 4 hours, while the actual time of use when fully charged is between 8 and 10 hours, according to the listening volume. During the charging phase, the LEDs on the earcups will be switched on and red; when charging is complete they'll became green.

It is advisable to recharge the battery in environments with temperatures between 10 $^{\circ}$ C and 30 $^{\circ}$ C. Charging in other environments may not be as effective



* The charging cable may also come with a single proprietary connector; this solution depends on the equipment rented or purchased.

Volume Adjustment

By turning the **Volume Control Wheel** (Pic. 1) it is possible to adjust the listening volume.

ΕN

FAQ - Frequently Asked Questions

QUESTION	ANSWER
Can I use the SX-809 with my mobile phone via Bluetooth®?	No, the SX-809 headset is designed to work exclusively with Silentsystem ® transmitters, which work with RF (Radio Frequency) technology.
Does the SX-809 have a built-in microphone?	No, if you have a Silentsystem ® portable transmitter (eg. TX-300-Mobi) you must necessarily use the microphone that comes with the transmitter.

Trademarks & Patents

TRADEMARK / PATENT	INFORMATIONS
Headphones Design SX-809 Super Power Bass ®	Brand SILENTSYSTEM ® Model No. SX-809 Super Power Bass Patent No. 0000101677 Deposit Date 27 giugno 2014 Class Code 1401 Country: Italy
Trademark SILENTSYSTEM ®	Req. Number 017042045 Playable in any character, size, and color Country: Europe, Italy, Kazakhstan, USA, Costa Rica, China, Hong Kong, Switzerland, Argentina
Trademark SUPER POWER BASS ®	Trademark No. 0001633691 Country: Italy

